



FR Guide de l'utilisateur
 EN User's guide
 DE Bedienungsanleitung
 NL Gebruiksaanwijzing
 ES Guía del usuario
 PT Guia del usuario
 IT Manuale d'uso
 DA Brugsvejledning
 NO Bruksanvisning
 SV Användarhandbok
 FI Käyttöopas
 TR Kullanım kılavuzu
 EL Οδηγός χρήσης
 PL Instrukcja obsługi
 CS Návod k použití
 SK Používateľská príručka

HU Használati útmutató
 SL Navodila za uporabnika
 RU Руководство пользователя
 UK Посібник користувача
 HR Upute za uporabu
 RO Ghidul utilizatorului
 ET Kasutusjuhend
 LT Naudotojo vadovas
 LV Lietošanas pamācība
 BG Ръководство на потребителя
 SR Korisničko uputstvo
 BS Korisnički priručnik
 TH คู่มือผู้ใช้
 AR دليل الإستعمال



www.tefal.com www.calor.fr

FR Pour plus d'informations sur l'utilisation / EN For further usage information / DE Weitere Informationen zur Bedienung / NL Voor meer informatie over het gebruik / ES Para obtener más información sobre su uso / PT Para obter mais informações sobre a utilização / IT Per maggiori informazioni sull'utilizzo / DA Yderligere informationer vedrørende betjening / NO For mer informasjon om bruken / SV För mer information om användningen / FI Lisätietoja käytöstä varten / TR Kullanım hakkında daha fazla bilgi için / EL Για περισσότερες πληροφορίες σχετικά με τη χρήση / PL Więcej informacji na temat korzystania z urządzenia / CS Pro více informací o použití / SK Pre ďalšie informácie o používaní / HU A használatra vonatkozó további információk / SL Več informacij o uporabi / RU Для получения более подробной информации об эксплуатации / UK Для отримання детальної інформації щодо експлуатації / HR Za više informacija o upotrebi / RO Pentru mai multe informații privind utilizarea / ET Täiendava teabe saamiseks kasutamise kohta / LT Daugiau informacijos apie naudojimą / LV Lai iegūtu vairāk informācijas par lietošanu / BG За още информация относно употребата / SR Za dodatne informacije o korišćenju / BS Za dodatne informacije o korišćenju / TH เพื่อข้อมูลเพิ่มเติมเกี่ยวกับการใช้งาน / AR للمزيد من المعلومات حول الإستعمال

 www.tefal.com
www.calor.fr 

www.tefal.com  www.calor.fr

2.

www.tefal.com

www.calor.fr

ON

OK

ON / OFF

ON

MIN

SYNTH.

NORMAL

MIN

SYNTH.

SILK

NORMAL

OK

x3

NO

2.

Pro Express X-Pert Care

Diagram illustrating the temperature control slider and the steam control buttons.

The temperature control slider is shown with settings for SYNTH, SILK, WOOL, COTTON, and LINEN. The steam control buttons are shown with settings for DELICATE, NORMAL, and MAX.

The diagram shows the iron's settings for different fabric types and the corresponding steam output levels.

Pro Express Care

Diagram illustrating the steam control buttons and the ECO mode.

The steam control buttons are shown with settings for DELICATE, NORMAL, and MAX. The ECO mode is shown with a green circle and the word ECO.

The diagram shows the iron's settings for different fabric types and the corresponding steam output levels.

ECO

Diagram illustrating the ECO mode and the steam control buttons.

The ECO mode is shown with a green circle and the word ECO. The steam control buttons are shown with settings for DELICATE, NORMAL, and MAX.

The diagram shows the iron's settings for different fabric types and the corresponding steam output levels.

